

USER'S MANUAL



PH-DUP3017

Up to 64 Ports, RS-232 Serial to Ethernet, Terminal Server/Client

IPEX

(IP Electronix)

23 February 2022

Contents

1.	INTRODUCTION	3
2.	SPECIFICATIONS	3
3.	PACKAGE CHECKLIST	ERROR! BOOKMARK NOT DEFINED.
4.	FRONT PANEL	4
5.	RS-232 SERIAL PORTS PIN CONFIGURATION (PORT #1 ~ #4)	5
6.	RS-232 CONNECTING METHODS	5
7.	CONNECTION DIAGRAM	7
8.	DEVICE CONFIGURATION WEBPAGE	9
9.	NETWORK CONNECTION TESTING	16
10.	CONNECTING TO DEVICE VIA TCP SOCKET	18
11.	REDIRECTING	20
12.	GUARANTEE	22
13.	TECHNICAL SUPPORT	22

1. Introduction

IPEX PH-DUP3017 Terminal Server/Client is a simple solution for connecting serial devices to a network which results in having up to 64 RS-232 serial ports over Ethernet network. This converter uses transparent communicate protocol, so it is not required to understand complex Ethernet TCP/IP protocol, and no modification in serial programs is needed. It operates as a Real COM, TCP Server, TCP Client, UDP Server and UDP Client Full-Duplex converter and supports bidirectional connection.

PH-DUP3017 is designed for industrial usage and is useful for connecting any device with a serial interface to a computer via Ethernet supported network like LAN, WAN ... and can be used in Industrial Automation, Telecommunications, SCADA Systems, DCS Systems


Protection against Surge, ESD and EMI is implemented in its design and it has 3kV isolation between Ethernet and RS-232 sides.

PH-DUP3017 consists of a power supply card and a number of terminal server cards.
Each server terminal card is actually an **PH232Ex8** converter, as described below.

2. Specifications

- **Number of Ports:** Up to #64 Ports RS-232 DTE Serial Port
- **Serial Standard:** Meets or Exceeds the Requirements of TIA/EIA-232-F and ITU v.28 Standards.
- **Network Protocols:** ICMP, IP, TCP, UDP, DHCP, Telnet, DNS, ARP, HTTP.
- **RS-232 Signal (Full Handshake Support):** TxD, RxD, DTR, RTS, DSR, CTS, GND.
- **Baud Rates:** 50, 75, 110, 150, 300, 450, 600, 900, 1200, 1800, 2400, 3600, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 56000, 57600, 76800, 115200 bps and Custom Baud Rate is Selectable.
- **RS-232 Parity:** Even, Odd, None, Mark and Space; Selectable.
- **Power (Green)** LED Indicator
- **Transmit (Blue) and Receive (Yellow)** LED Indicator for All Ports
- **ESD Protection:** RS-232 Bus-Pin ESD Protection Exceeds ± 15 kV Using Human-Body Model (HBM).
- **Operating Temperature:** -20°C to +85°C (-4°F to +185°F).
- **1 Year Guarantee and 5 Years Support**

3. Front Panel



General Indicators:

POWER LED (Green): It is turned ON, when the power supply connects to +VDC and GND correctly.

Port Indicators:


RX LED (Yellow): It is blinking when the device receive data on serial port.

TX LED (Green): It is blinking when data is transmitting from the device serial port.

REDIRECT IN (YELLOW): It is turned on if data from other ports are redirected to this port.


REDIRECT OUT (GREEN): It is turned on if data from the port are redirected to any other port.

4. RS-232 Serial Ports Pin Configuration (PORT #1 ~ #8)


	Pin	RS-232 (DTE)
	1	DSR (in)
	2	RTS (out)
	3	GND
	4	TxD (out)
	5	RxD (in)
	6	DCD (in)
	7	CTS (in)
	8	DTR (out)

5. RS-232 Connecting methods

8-pin RJ45 to Female DB9




8-pin RJ45 to Male DB9



6. Connection Diagram


6.1 PH232Ex8 as a Terminal Server

The below diagram is a typical connection configuration of PH232Ex8. You can connect four devices with a RS-232 serial port to any RS-232 serial port of the PH232Ex8. Then you can connect to the device, behind the network by any application software you want by opening a TCP or UDP Socket without need of any auxiliary driver.



6.2 Client/Server, Peer to Peer Connection


If you want to connect two devices which have only RS-232 Ports to each other via Ethernet network, you can use this connecting method. Take two PH232Ex8. Set one PH232Ex8 as Server and another one as Client with adding Remote Server IP and Port Number on it. These two converters are connecting automatically via network to each other. You can easily assign each port from one device to each port from another device by setting IP and Port Number.



7. Device Configuration Webpage

NOTE: PH232Ex8 consists of two PH232Ex4, each of them has its own LAN connection and IP address. Please read PH232Ex4 User's Manual carefully.

To open device configuration webpage, enter the device IP on your web browser address bar like this figure:




The Default device IP Address is **192.168.1.100** and the default Subnet Mask is: **255.255.255.0**

Now enter user name and password to pass the authentication procedure. Default User Name is **admin** and default password is **admin** too.


User Name: **admin**

Password: **admin**



7.1 Device Information Webpage

You can see some general information about the device such as MAC address, Firmware and Hardware version and ... in this page.



The screenshot shows a web browser window with the address bar displaying "192.168.1.100". The webpage is titled "PH232Ex4 Remote Configuration" and features the IPEX logo. On the left, there is a sidebar with navigation buttons: "Device Info" (highlighted in green), "Security", "Network Settings", "Port Settings", and "Pinout Guide". The main content area is titled "Device Information" and contains a table with the following data:

Device Name:	PH232Ex4
IP Address:	192.168.1.100
MAC Address:	00:04:a3:00:05:7d
Production Date:	03/OCT/2018
Hardware Version:	V1.1
Firmware Version:	V1.1
User's Manual:	PH232Ex4-UM-001.pdf
Data Sheet:	PH232Ex4-DS-001.pdf

At the bottom of the page, there is a footer with the text: "Visit Our Website at: <http://www.ipelectronix.com>" and "For Technical Support Mail to: support@ipelectronix.com".

7.2 Security

You can change device configuration webpage user name and password in this page.

The screenshot shows a web browser window with the address bar displaying "192.168.1.100/security.htm". The page title is "PH232Ex4 Remote Configuration". On the left, there is a sidebar with navigation buttons: "Device Info", "Security" (highlighted in green), "Network Settings", "Port Settings", and "Pinout Guide". The main content area is titled "Security" and contains a form with the following fields:

Current User Name:	<input type="text" value="admin"/>
Current Password:	<input type="password"/>
New User Name:	<input type="text" value="admin"/>
New Password:	<input type="password"/>
Confirm New Password:	<input type="password"/>

Below the form is a "Save To Device" button. At the bottom of the page, there is a footer with the following text:

Visit Our Website at: <http://www.ipelectronix.com>
For Technical Support Mail to: support@ipelectronix.com

7.3 Network Settings

You can change all the network settings, such as device IP Address in this page.

It is important to enter valid data in this section. If you are not sure about your network settings such as DNS address and ..., you should consult to your network administrator before any changing in these settings.

The screenshot shows a web browser window with the address bar displaying "192.168.1.100/network.htm". The page title is "PH232Ex4 Remote Configuration". On the left, there is a sidebar with navigation links: "Device Info", "Security", "Network Settings" (highlighted in green), "Port Settings", and "Pinout Guide". The main content area is titled "Network Settings" and contains a form with the following fields:

Host Name:	PH232EX4-00057D
MAC Address:	00:04:a3:00:05:7d
IP Type:	<input checked="" type="radio"/> Static <input type="radio"/> DHCP
IP Address:	192.168.1.100
Subnet Mask:	255.255.255.0
Gateway Address:	0.0.0.0
Primary DNS Address:	0.0.0.0
Secondary DNS Address:	0.0.0.0
Net Command Code:	1111
UDP Command Port:	9765

Below the form is a "Save To Device" button. At the bottom of the page, there is a footer with the text: "Visit Our Website at: <http://www.ipelectronix.com>" and "For Technical Support Mail to: support@ipelectronix.com".

7.4 PORT Settings

You can see and change all the port settings in this page.

The screenshot shows a web browser window with the address bar displaying "192.168.1.100/port1.htm". The page title is "PH232Ex4 Remote Configuration". On the left, there is a sidebar with navigation buttons: "Device Info", "Security", "Network Settings", "Port Settings" (highlighted in green), and "Pinout Guide". The main content area is titled "Port 1 Settings".

RS-232 Settings

Baud Rate:	9600	bps
Data Length:	8	bits
Parity:	None	
Stop Bits:	1	bits
Flow Control:	None	
Redirect to Port[s] :	<input type="checkbox"/> P1 <input type="checkbox"/> P2 <input type="checkbox"/> P3 <input type="checkbox"/> P4	

LAN Settings


<input checked="" type="radio"/> TCP Server	Local Listening Port :	9761
	Remote Server IP:	192.168.1.101
<input type="radio"/> TCP Client	Remote Server Port:	9761
	Local Listening Port:	9761
<input type="radio"/> UDP	Destination IP 1:	192.168.1.101
	Destination Port 1:	9861
	Destination IP 2:	0.0.0.0
	Destination Port 2:	9961

Save to Device

Visit Our Website at: <http://www.ipelectronix.com>
For Technical Support Mail to: support@ipelectronix.com

7.5 Pinout Guide

RS-232 Port pinout is seen in this page.



The screenshot shows a web browser window displaying the PH232Ex4 Remote Configuration page. The page has a sidebar with navigation links: Device Info, Security, Network Settings, Port Settings, and Pinout Guide (which is highlighted). The main content area is titled 'PH232Ex4, RS-232 Ports Pinout (DTE)' and contains a table of pinout information.

Pin #	Name	Task	Type
1	DSR	Data Set Ready	Input
2	RTS	Request To Send	Output
3	GND	Ground	GND
4	TxD	Transmit Data	Output
5	RxD	Receive Data	Input
6	DCD	Data Carrier Detect	Input
7	CTS	Clear To Send	Input
8	DTR	Data Terminal Ready	Output

Below the table, it specifies 'Connector Type: RJ-45 Female' and shows a diagram of the connector with pins labeled RX (yellow), TX (green), OUT (green), and IN (yellow).

At the bottom of the page, there is a footer with the following text:

Visit Our Website at: <http://www.ipelectronix.com>
 For Technical Support Mail to: support@ipelectronix.com

7.6 Default Settings:

Default IP Address: 192.168.1.100

Default Subnet Mask: 255.255.255.0


Default User Name: admin

Default Password: admin

IMPORTANT NOTICE:

If you change the device IP and forget it, you can see the new IP Address on the serial port. Whenever you turn on the device, it sends its IP Address and Subnet Mask to the RS-232 PORT1. The port settings for watching device IP is fixed to 9600, 8, n, 1. You can easily see this IP Address and Subnet Mask by using a Terminal Emulation Software such as Microsoft Hyper Terminal.

You can Reset the device to its factory default settings in this page if necessary.




8. Network Connection Testing

Connect PH232Ex8 to the Ethernet based network by connecting RJ45 LAN socket to network via a switch or Hub by an ordinary CAT5 or CAT6 cable. If everything is set properly, the green and yellow LEDs on the PH232Ex8's **RJ45 socket** will blink.


Now it is important to check the network wiring topology and testing all the cables, routers, switches ... in the route from PH232Ex8 to the computer. This test is done simply by using PING command from computer.

Go to Windows command prompt, (press WINDOWS KEY + R to going to run dialog and then type CMD and press enter):



Type ping with the device IP address, for example "ping 192.168.1.100" and press Enter.

Now you should see the ping response from the device.



```
Administrator: D:\Windows\system32\cmd.exe


C:\>ping 192.168.1.100

Pinging 192.168.1.100 with 32 bytes of data:
Reply from 192.168.1.100: bytes=32 time=1ms TTL=128
Reply from 192.168.1.100: bytes=32 time=1ms TTL=128
Reply from 192.168.1.100: bytes=32 time=1ms TTL=128
Reply from 192.168.1.100: bytes=32 time=1ms TTL=128

Ping statistics for 192.168.1.100:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 1ms, Average = 1ms

C:\>_
```

If there are any problems in the network, you could not see response from the device:



```
Administrator: D:\Windows\system32\cmd.exe

C:\>ping 192.168.1.100

Pinging 192.168.1.100 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 192.168.1.100:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\>
```


If you see this timeout window, you can't continue installation and first you should solve network problem by consulting your network administrator.

9. Connecting to Device via TCP Socket

It is possible to directly connect to PH232Ex4 RS-232 Serial Ports from any node of the network by using socket programming. This is simply done if you know only PH232Ex4 IP Address and socket port number for each Port. The default port numbers are as follow:

- Port 1: 9761
- Port 2: 9762
- Port 3: 9763
- Port 4: 9764


For example, we connect to Port 1 by means of Hyper Terminal. Run Hyperterm.exe and from properties dialog box, select "TCP/IP (Winsock)":



Enter device IP Address in the "Host address:" section, for example 192.168.1.100 and the port number in the "Port Number:" section (port number for Port 1 is 9761), then click on OK.

Now if you type some characters, you can see that port 1 TX Blue LED is blinking that means the data is sent to PH232Ex4 port 1.

NOTICE: Don't forget to set PH232Ex4 in **SERVER Mode** for this method of connection.



10.Redirecting

All the Terminal Servers produced by **IP Electronix** have Redirecting ability. It means you can re-transmit all the received data from one serial port input (Rx/D) to any other serial port[s] output (Tx/D).


For example, if your device has more than two ports and you redirect one port to two other ports, you can simply make an Y-Switch.

If one serial port is redirected to itself, you have a LOOP line that is very useful for testing a communication line.

There are two ways to set redirect for each port, setting in main configuration webpage of the device by a web-browser or sending network command line via UDP packets.

10.1 Setting Redirect by Web-Browser

As it is shown in the picture below, go to the device configuration page by means of a web-browser such as Google-Chrome or Fire-Fox and choose Port Settings:



Port 1 Settings

RS-232 Settings

Baud Rate:	9600	bps
Data Length:	8	bits
Parity:	None	
Stop Bits:	1	bits
Flow Control:	None	
Redirect to Port[s] :	<input type="checkbox"/> P1 <input checked="" type="checkbox"/> P2 <input type="checkbox"/> P3 <input type="checkbox"/> P4	

LAN Settings

<input checked="" type="radio"/> TCP Server	Local Listening Port :	9761
<input type="radio"/> TCP Client	Remote Server IP:	192.168.1.101
	Remote Server Port:	9761
	Local Listening Port:	9761
	Destination IP 1:	192.168.1.101

Now select destination port which you want to redirect current port to it. You can select more than one port for redirecting and also can redirect a port to itself.

10.2 Setting Redirect by UDP Network Command

To send redirect command from a remote workstation or software to the device, we need IP number or Host-Name and the UDP Port-Number. The default UDP Port-Number is 9765 and you can change this port number if necessary. We also need to know the device Remote Command Password which is a Four-Digit number that you can see it in Network Settings and also can change it there if necessary.

The Command Frame and Device Response as follows:

1) Change Redirect Setting Command

This command consists of 6 bytes as follows:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0x01	CODE-MSB	CODE-LSB	'W'	pn	status

And the device response consists of 6 bytes as follows:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
0x01	CODE-MSB	CODE-LSB	'S'	pn	status

These bytes are:

0x01: constant binary value = 0x01

CODE-MSB: Most Significant 8 bits of Security Code

CODE-LSB: Least Significant 8 bits of Security Code

'W': ASCII Character 'W', Write Command

pn: Port Number, a binary value from 0x00 to 0x03 for PORT1 to PORT4

status: Redirect Status Byte that is consists of 8 bits as follow:

Status Byte:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
X	X	X	X	P4	P3	P2	P1

X: Don't Care

P[i] = 1, means redirect to this port i is enabled

P[i] = 0, means redirect to this port i is disabled

Security Code is a 16-Bits Integer password that can be a number from 1000 to 9999 (decimal). The default value is 1111 decimal (0x0457 Hexadecimal).

For example, if the device password is 1111 and we want to redirect the port number 4 to the ports number 1 & 3, we should send this six-byte frame to the device: 0x01 0x04 0x57 0x57 0x03 0x05

2) Read Redirect Status Command

This command is same as the change command, but we should send character 'R' instead of 'W', and status byte is not required.

1	2	3	4	5
0x01	CODE-MSB	CODE-LSB	'R'	Pn

The device response is similar to the previous one.

11. Guarantee

All products manufactured by **IPEX** are under warranty regarding defective materials for a period of one year from the date of delivery to the original purchaser.

12. Technical Support

If you have any technical question or need any technical support, please contact us using this Email address: support@ipelectronix.com.